


### VRX 1810 Vane Rotary Actuators 1 inch (25 mm) Bore

**Models:** 1810-0110, 1810-0111, 1810-0112, 1810-0113,  
1810-0116, 1810-0117, 1810-0118, 1810-0119


#### 100° Rotation, Dual Vane



MODEL NUMBER	ROTATION	VANE / STATOR	SHAFT	OPTION
1810-0113	280°	Single	Single	
1810-0112	280°	Single	Dual	
1810-0111	100°	Dual	Single	
1810-0110	100°	Dual	Dual	
1810-0119	280°	Single	Single	Front Flange Mount
1810-0118	280°	Single	Dual	Front Flange Mount
1810-0117	100°	Dual	Single	Front Flange Mount
1810-0116	100°	Dual	Dual	Front Flange Mount

ITEM	PART NO.	DESCRIPTION	100°		280°	
			1810-0110 1810-0116	1810-0111 1810-0117	1810-0112 1810-0118	1810-0113 1810-0119
1	1810-1128	FLAT HEAD CAP SCREW	8	8	8	8
2	1810-1125	SHOULDER NUT	8	8	8	8
3	1810-1106	BEARING COVER	2	2	2	2
4	1812-1010	BALL BEARING	2	2	2	2
5	1810-1127	BEARING SHIM	A/R	A/R	A/R	A/R
6	1810-9035	HEAD KIT, Dual Vane	2	2	-	-
	1810-9036	HEAD KIT, Single Vane	-	-	1	1
	1810-9037	HEAD KIT, Single Vane	-	-	1	1
7	1810-1131	O-RING	2	2	2	2
8	1810-1103	O-RING	2	2	2	2
9	1810-9053	STATOR	2	2	1	1
10	1810-9052	ROTOR, Dual Vane, Dual Shaft	1	-	-	-
	1810-9069	ROTOR, Dual Vane, Single Shaft	-	1	-	-
	1810-9061	ROTOR, Single Vane, Dual Shaft	-	-	1	-
	1810-9059	ROTOR, Single Vane, Single Shaft	-	-	-	1
11	1810-1145	TUBE	1	1	1	1
12	1810-1118	TIE ROD	4	4	4	4

#### 280° Rotation, Single Vane



**Pneumatic Service:** The VRX actuator should be operated with 100 PSI maximum pneumatic service lubricated with a non-detergent SAE 30 weight oil.

**Axial Loading:** Heavy end thrust loading of the actuator shaft is not recommended. Use an isolating coupling which takes the load and does not distribute it to the actuator shaft.

**Internal Stops:** Do not use internal stops to stop rotation except with loads whose combined weight and speed do not generate more than 0.15 inch-pounds (0.02 Newton-meters) of kinetic energy. Backlash (lost motion) between the shaft and load should be avoided.

**External Stops:** External stops are recommended for higher inertia loads to avoid vane and stator damage. Stops should be securely mounted to machine framework.

**DISASSEMBLY NOTE:**

VRX Ball Bearings (#4) are installed using retaining compound. Additional force may be required to separate the Ball Bearings (#4) during disassembly. Also note that the Ball Bearing (#4) may stay attached to the Rotor (#10) or to the Head (#6).


**ASSEMBLY INSTRUCTIONS – 100° ACTUATOR**

1. Use Teflon®-additive grease when lubrication is required.
2. Lubricate and install small O-Ring (#7) into groove in center bore of each Head (#6).
3. Lubricate and install large O-Ring (#8) into groove on face of each Head (#6).
4. Lubricate rubber surfaces and insert two [2] Stators (#9) into one Head (#6) by aligning the dowel pins with the holes in the Head (#6).
5. Lubricate rubber surfaces and insert Rotor (#10) between the two [2] Stators (#9) and into the center bore of the Head (#6).
6. Lightly lubricate the inside diameter of the Tube (#11) and slide over the Stators (#9) and Rotor (#10) until engaging the Head (#6).
7. Align and install the other Head (#6) onto the dowel pins of the two [2] Stators (#9) and the shaft of the Rotor (#10) through the center bore. NOTE: Assemble with the ports on the same side of both Heads (#6).
8. Thread four [4] Shoulder Nuts (#2) half way onto each of the four [4] Tie Rods (#12) then insert each Tie Rod (#12) through the holes in both Heads (#6).
9. Thread the remaining four [4] Shoulder Nuts (#2) onto the four [4] Tie Rods (#12). Shoulder Nuts (#2) must be inserted into Head (#6) then threaded onto the Tie Rod (#12).
10. Use a criss-cross pattern to evenly tighten each of the Shoulder Nuts (#2). Torque Shoulder Nuts (#2) to 20 in-lbs (2.26 N-m).

**ASSEMBLY INSTRUCTIONS – 280° ACTUATOR**

1. Use Teflon®-additive grease when lubrication is required.
2. Lubricate and install small O-Ring (#7) into groove in center bore of each Head (#6).
3. Lubricate and install large O-Ring (#8) into groove on face of each Head (#6).
4. Lubricate rubber surfaces and insert Stator (#9) into one Head (#6) by aligning the dowel pin with the hole in the Head (#6).
5. Lubricate rubber surfaces and insert Rotor (#10) next to the Stator (#9) and into the center bore of the Head (#6). Rotate the Rotor (#10) so the vane is across from the Stator (#9).
6. Lightly lubricate the inside diameter of the Tube (#11) and slide over the Stator (#9) and Rotor (#10) until engaging the Head (#6).
7. Align and install the other Head (#6) onto the dowel pin of the Stator (#9) and the shaft of the Rotor (#10) through the center bore. NOTE: Assemble with the ports on the same side of both Heads (#6).

**Optional Front Flange Assembly**



ITEM	PART NO.	DESCRIPTION	1810-9031
1	1810-1112	FLANGE PLATE	1
2	0910-1040	SOCKET HEAD CAP SCREW	4

11. Place two [2] Bearing Shims (#5) over Rotor (#10) shaft and into bearing diameter in Head (#6).
  12. Use retaining compound on the outside and inside diameter of the two [2] Ball Bearings (#4) then slide Ball Bearing (#4) over and into the bore of each Head (#6). NOTE: The Ball Bearing (#4) will bottom out on the Rotor (#10) shaft not the bore in the Head (#6).
  13. Install Bearing Cover (#3) onto each of the Heads (#6) using Flat Head Screws (#1).
8. Thread four [4] Shoulder Nuts (#2) half way onto each the four [4] Tie Rods (#12) then insert each Tie Rod (#12) through the holes in both Heads (#6).
  9. Thread the remaining four [4] Shoulder Nuts (#2) onto the four [4] Tie Rods (#12). Shoulder Nuts (#2) must be inserted into Head (#6) then threaded onto the Tie Rod (#12).
  10. Use a criss-cross pattern to evenly tighten each of the Shoulder Nuts (#2). Torque Shoulder Nuts (#2) to 20 in-lbs (2.26 N-m).
  11. Place two [2] Bearing Shims (#5) over Rotor (#10) shaft and into bearing diameter in Head (#6).
  12. Use retaining compound on the outside and inside diameter of the two [2] Ball Bearings (#4) then slide Ball Bearing (#4) over and into the bore of each Head (#6). NOTE: The Ball Bearing (#4) will bottom out on the Rotor (#10) shaft not the bore in the Head (#6).
  13. Install Bearing Cover (#3) onto each of the Heads (#6) using Flat Head Screws (#1).

Teflon® is a registered trademark of the E.I.DuPont de Nemours Co., [www.dupont.com](http://www.dupont.com)



3800 County Road 116, Hamel, MN 55340  
<http://www.Tolomatic.com> • Email: [Help@Tolomatic.com](mailto:Help@Tolomatic.com)  
 Phone: (763) 478-8000 • Fax: (763) 478-8080 • Toll Free: 1-800-328-2174



Information furnished is believed to be accurate and reliable. However, Tolomatic assumes no responsibility for its use or for any errors that may appear in this document. Tolomatic reserves the right to change the design or operation of the equipment described herein and any associated motion products without notice. Information in this document is subject to change without notice.